

# QUICK START GUIDE

BASE CAMP™




# TABLE OF CONTENTS

1. MAIN PAGE
2. SETTINGS PAGE
3. EVEREST KEYBOARD

Thank you for choosing Mountain to help you to Reach your Summit! In this guide, we'll introduce you to Base Camp™, enabling you to customize your Mountain exactly to your liking.




# GENERAL



Base Camp's user-centric design was specifically created to be as easy and straight forward as possible. It flows from left to right, so that every configuration you'd like to make starts on the left hand side and walks through submenus to the right. The image below shows the recording of a macro in 5 easy steps that include:

1. Choosing the Macro menu,
2. Creating a new Macro,
3. Selection of the devices to be recorded,
4. Recording
5. Playback settings and saving.

# 1. MAIN PAGE



1. Main menu button (Mountain logo), this button can be clicked at any time to return to the home screen

*Note: the yellow highlight above the Mountain logo as shown in above screenshot highlights the currently active page.*

2. Current Base Camp Software version, updates can be performed through settings menu (see paragraph 2)

3. Selecting the Mountain product you wish to configure

4. Software Settings button (see this guide paragraph 2)


5. Press – to minimize Base Camp and send it to system tray, X to close it

6. These buttons will lead you to:

- a. Our support page including manuals, FAQ, guides and contact information.
- b. Our website <https://mountain.gg>
- c. Our store <https://mountainggshop.com> that carries not only Mountain products but carefully selected accessories and upgrades for all your keyboard needs

7. Links to our social channels

## 2. SOFTWARE SETTINGS



1. Version will show you the currently installed version of Base Camp

2. Manually check for updates of Base Camp (firmware update for each product is on product settings)

3. Check this box to have Base Camp launch automatically each time you start your computer



4. Check this box to allow for Base Camp to periodically ping our server for software updates. If not checked, you will not receive automatic updates

5. Change the language of Base Camp

6. Links to our social channels

7. Buttons with links to our support pages and material

# 3. KEYBOARD EVEREST



## A. PROFILE

1. Currently active sub-menu. If set, the profile button shows the user-selected image

2. By default, profile 1 is active. More profiles can be added by pressing the “New Profile” button. Up to 5 profiles can be created per product

3. Delete selected profile

4. Import previously exported profiles or profiles shared by the community

5. Profiles will by default be named “Profile X” with X being ascending numbers, you can enter a custom name here

6. To change the picture on the profile click this button to select a default image or upload your own image (s)

7. To switch to this profile automatically whenever a certain application or game is launched, use this button to browse to this application or game

8. Export will allow you to save the profile to a file on your system, as a backup or to share with the community

9. Duplicate creates an exact copy of the selected profile

10. Reset to default will set everything in this current profile back to default, including lighting, key bindings and any custom settings

# B. LIGHTING



1. The available list of backlight effects, this varies per product and effects may be added or removed by firmware updates.

2. Different effects can have various types available, this will vary per effect:

- Single color
- Dual color
- Rainbow (full RGB 16.7m color spectrum)

3. The color picker will open once the color square is pressed on the requested type. The specific color of choice can be selected through different means:

- Point and click on the color square and bar
- HEX code
- RGB code

*Note: RGB and HEX codes are automatically generated by point and click and vice versa*

d. You can save your favorite custom colors by pressing the + icon and delete them via the trashcan icon. Your saved colors will remain on the bottom of the color picker window

4. For selected active effects, such as breathing and color wave, you can select the animation speed in 5 steps from slower to faster

5. Brightness of all effects can be adjusted in 5 levels from 0% to 100%

# C. KEY BINDING



1. Binding shows a list of all custom key bindings

2. Legends to indicate keys that are in their default state (grey), selected (white border), bound (blue) or disabled (red)

3. To select a key for rebinding, click on the key in the keyboard image

4. Pick a function for the selected key:

- a. Default
- b. Disable
- c. OS Commands such as task manager, browser, calculator etc.
- d. Run program: Launch any application (EXE) on your system
- e. Run Macro: Run a Macro created in the Macro section of Base Camp
- f. Media: Play, pause, forward, backward, mute, etc.
- g. Keyboard shortcuts: CTRL / ALT / SHIFT / WIN + keystroke
- h. Mouse buttons: Left mouse button, scroll, etc.


5. Menu to apply the desired function, such as OS Command → Task Manger

6. Choose if you wish to have the key to perform its selected function either on pressing or releasing

7. In addition to the features above, the 4 display keys can either be used with default images or custom images of your choosing. Click the Image box to select or upload an image with up to 72x72 pixels

8. The sync button will apply your key binding configuration to all profiles

# D. MACRO



1. Macro Library shows a list of all macros
2. Pressing the “+ New Macro” button will start the sequence to create a new macro, guided by Base Camp’s macro wizard
3. Enter a name for your macro
4. Choose which device inputs should be recorded
5. Delay is the time between key strokes, this can be set in 3 different modes:
  - a. Record delay: Records the exact delay of your inputs during recording
  - b. Custom delay: Enter a custom value that will be applied to all inputs during recording
  - c. No delay: No noticeable delay (0.1ms) on all inputs during recording
6. Press start to begin recording. Perform the inputs you wish to record. Click stop recording when the desired input sequence is complete

7. The green and red arrows indicate press and release of keys, this visualization can be grouped or separated with this slider
8. The trashcan symbol next to an input deletes the respective action, not the entire macro
9. Playback gives you different options of macro execution:
  - a. Play once: Play the macro only once when the macro button is pressed
  - b. Hold: Play the macro for as long as the macro button is pressed
  - c. Repeat: Play the macro when the button is pressed until the button is pressed again
10. Check which key the macro is assigned to. By default, a new macro remains unassigned until it’s being assigned to a button in the Key Binding menu
11. Click here to save your macro. It’s now listed under Macro Library and ready to be assigned to a key of your choosing under Key Binding

*Note: Macros are cross-product compatible*

# DISPLAY DIAL



1. The list of available menus. Disable the menus to remove hide them on your Display Dial

2. “Screensaver” is an imagine that will display after a certain time of inactivity

a. The default Mountain logo can be replaced by a custom image in either bmp, jpg or png format. “Screensaver after” needs to be checked in order for the image to show

b. Idle time to pass before the image appears on Display Dial


c. In addition to screensaver, the display can be turned off entirely after the chosen time in seconds. This may enhance the lifespan of your display

3. The menu highlight color can be changed to any color of your choosing

4. The Display Dial’s clock feature can be set to digital or analog watch faces. The digital display can be set to either 12H or 24H mode

5. Reset will return all dial settings back to factory default

# E. SETTINGS



1. Read out your device firmware and manually search for updates

2. Game Mode (FN+Pause) disables the Windows key by default. Other hotkeys that could accidentally minimize your game can be disabled as well

3. The sync button will apply your settings to all profiles

4. For Everest Max the indicator LEDs (Caps Lock, Scroll Lock, Num Lock and Game Mode) are built into the media dock. If you don't have a Media Dock connected, you can check this box to have the LEDs on the keys themselves turn on/off to indicate if the respective button is activated

5. Select your keyboard's layout

6. Reset will return all settings back to factory default