



1MORE Triple Driver BT In-Ear Headphones

USER MANUAL

Power

Power On: Press and hold the power button for 2 seconds. The blue light will go on for 1 second.

Power Off: Press and hold the power button for 4 seconds. The red light will flash for 1 second.

Bluetooth Pairing

The pairing mode starts automatically the first time it was turned on. The red and blue lights will flash alternately.

* Pairing:



When the headphones are on, press and hold the power button for 2 seconds to start the pairing mode.

When the headphones are off, press and hold the power button for 4 seconds to start the pairing mode.

Placement



Fit




Charging

The red light is on while charging. When charging is finished, the red light will turn off.


Control Box

Phone



* May not be compatible with some Android cellphones.

Music



* Above functions may vary with different devices.

Extra Functions

Security Pairing: If the pairing phone has Bluetooth prior to 3.0, please use the default security code "0000".

Unpairing: Press and hold Vol+ and Vol- for 3 seconds. The headphones will switch to automatic discovery mode.

Battery/Volume Display: Currently supports iOS only; may not support other operating systems.

Multi-Device Connection: When there are two phones connected to the headphones, only one of the phones will be supported.

If Out of Wireless Connection Range: The headphones will try to reconnect for 5 minutes. Then they will turn off automatically if not connected to any device.

1MORE PRODUCT WARRANTY

1MORE products are warranted against defects in materials and craftsmanship for a period of one year from the date of original retail purchase, when used in accordance with 1MORE's user manuals. Under this warranty, your claim can be directed to 1MORE, even if you purchased the product from an authorized third party. During the warranty period, 1MORE will, at its sole option, repair or replace the original, defective parts or issue a refund in the amount of the original purchase price. This warranty does not include resulting from accidents, or from improper use, maintenance, or repair, or from other causes that are not defects in materials or craftsmanship.

Unfortunately, from time to time, 1MORE products are sold by dealers or internet sites that are not authorized by 1MORE. In most cases, products sold by these unauthorized companies were not purchased directly from 1MORE. 1MORE products sold by unauthorized details are sometimes:

1. Purchased on a "gray" market from other countries and illegally sold in the US
2. Counterfeit products not produced by 1MORE
3. Damaged, defective, or previously used products (B-stock)
4. Products stolen from authorized dealers or other sources

Unauthorized dealers may deceive consumers by implying the product is covered by 1MORE's warranty policy. Any products sold by unauthorized dealers are not entitled to 1MORE warranty coverage. We are using our best efforts to prohibit companies from taking advantage of consumers, but these practices still exist. To ensure quality and warranty on your purchase only buy from 1MORE USA authorized retailers:
1MORE.com
AMAZON USA 1MORE USA Inc. Storefront
AMAZON CANADA 1MORE USA Inc. Storefront
Ebay 1more-usa
Costco Wholesale Corporation

We Appreciate Your Business

We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one.

Important Safety Information

1. Long-term exposure to loud music may cause hearing damage. Avoid extreme volume when using headphones, especially for extended periods of time.
2. Do not use headphones while operating a motor vehicle or a bicycle. Doing so is dangerous and may violate local laws and regulations.
3. Do not use headphones if the inability to hear outside sounds may present a danger to you or others.
4. In dry air conditions, static electricity can cause ear tingling; this is not a product malfunction.
5. Do not drop, sit on, or allow the headphones to be immersed in water.
6. Do not wear headphones in the rain.
7. Adult supervision is required for children age 6 and under.

Environmental Consciousness

1MORE Triple Driver BT In-Ear Headphones meet the European RoHS2.0 (2011/65/EU) requirements.

Parts	Toxic Substances or Elements					
	Pb	Hg	Cd	Cr6VI	PBB	PBDE
Cable	x	o	o	o	o	o
PCBA	x	o	o	o	o	o
Plastic Parts	o	o	o	o	o	o
Metal Parts	x	o	o	o	o	o
Ear Pad	o	o	o	o	o	o

○ means that the amount of toxic substances or elements in a particular part is less than the requirements under the European RoHS2.0 (2011/65/EU) standard.

X means that the amount of toxic substances or elements in a particular part is more than the requirements under the European RoHS2.0 (2011/65/EU) standard. The "X" in above form meets European RoHS2.0 standard.



FAQ

1. The headphones don't turn on.

Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes.

2. The headphones and my device do not connect, or take a long time to connect.

- 1) Check that your headphones are in the "discoverable" mode (red and blue lights flash alternately).
- 2) Make sure that your headphones are not connected to other devices, and that your device is not connected to other Bluetooth devices.
- 3) We recommend that you press and hold both the Vol+ and Vol- buttons simultaneously for 3 seconds. Your headphones' pairing history will be cleared and will automatically enter the "discoverable" mode.
- 4) If they are still not connecting, restart your device to connect.

3. My Android device successfully connects to the headphones, but the headphones don't play music.

After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on.

4. My Android device successfully connects to the headphones, but there is no sound from the headphones while making phone calls.

After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.

5. The Bluetooth connection is not stable, causing some interruptions.

- 1) Try shortening the distance between your headphones and device. Avoid solid barriers in between.
- 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS.
- 3) Please make sure the Bluetooth antenna of your device is not blocked.

6. While using third party music/video player apps, some in-line remote control functions do not match those in the manual.

Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided.

7. I adjusted the in-line remote control to the maximum volume, but the actual volume still sounds low.

In different operating systems, especially some Android systems, the headphones and your device have separate volume control systems. Please adjust the volume controls on both the device and the headphones according to your preference.

Note: For more detailed product FAQs, please visit the product support section under www.1more.com

WEEE

Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household waste, it must be collected and disposed of separately to protect the environment.

Your 1MORE retailer will advise you of the correct way of disposal in your country.

Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.

CE

Hereby, 1MORE, declares that this Radio LAN device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

FCC

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1MORE